


INTERLIFT



ILD PARTS MANUAL

INTERLIFT, INC. a member of MBB

15939 Piuma Ave., Cerritos, CA 90703 Tel (562) 924-8218 Fax (562) 924-8318
Visit our website at www.interlift.net for information on additional product lines
If you received this product with damaged or missing parts, contact Interlift at 562-924-8318

7/1/04

Introduction

Each Interlift liftgate is manufactured to stringent quality standards for years of reliable service. To ensure maximum performance of your Interlift liftgate, always specify and use “OEM Parts” from Interlift.

This manual is a complete parts listing for ILD liftgates from 3500 lb. to 6600 lb. capacity. We have provided charts and diagrams to make the selection of the correct part as easy as possible.

This manual does not provide procedures for the servicing and repair of an Interlift liftgate. Service and repair should only be performed by an authorized Interlift distributor. For information on the nearest authorized Interlift distributor contact:

INTERLIFT, INC. a member of MBB.

15939 Piuma Ave
Cerritos, CA 90703
Tel (562) 924-8218
Fax (562) 924-8318

www.Interliftlift.net

** The use of non-standard or makeshift parts can be extremely hazardous and result in serious injury or death.*

Table of Contents

Introduction.....	2
General Information.....	4
Ordering Information.....	5
Key Components.....	6
H-Frame – ILD (All Models).....	7
Platform – ILD35 and ILD44.....	8
Platform – ILD55 and ILD66.....	9
Electrical Components.....	10
Slider Assembly.....	11
Hydraulic Assembly.....	12
Hydraulic Power Unit Assembly – ILD35 and ILD44.....	13
Hydraulic Power Unit Assembly – ILD55 and ILD66.....	14
Decals.....	15
Help and Service.....	16

General Information

MODEL NUMBER CODING

The code and model numbers of a liftgate are references to its size, type and capacity. Using these numbers when ordering or specifying improves customer satisfaction and delivery.

Model Number: **ILD4472**

<u>ILD</u>	<u>44</u>	<u>72</u>
1	2	3

1. **LIFTGATE TYPE**

ILD = Vertical Lift Style Liftgate

2. **WEIGHT CAPACITY**

35 = 3500 lb. Capacity

44 = 4400 lb. Capacity

55 = 5500 lb. Capacity

66 = 6600 lb. Capacity

3. **DEPTH OF PLATFORM** (not including ramp)

60 = 60" of platform loading area

72 = 72" of platform loading area

84 = 84" of platform loading area